CABINET PARTS

For Model: LEQ8000HQ0

(Designer White)

ELECTRIC DRYER



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

CABINET PARTS

For Model: LEQ8000HQ0
(Designer White)

Illus. No.	Part No.	DESCRIPTION
1		Literature Parts
	LIT3397618	Instructions, Installation
	LIT8282609	Use & Care Guide
	LIT3977704	Label, Wiring Diagram
2	343641	Screw, 10-16 x 1/2
3	693995	Screw, 8-18 x 3/8
4	238614	Bumper
5	3396795	Cover, Block
6	342043	Screw, 10-32 x 3/8
7	3396805	Panel, Rear
10	3406107	Door Switch Assembly
11	697773	Screw, 6-20 x 7/8
13	3357011	Screw, 10-16 x 1/2
14	692495	Spring, Door (2)
15	3394083	Clip, Front Panel (2)
16	3392100	Foot, Dryer
	279810	Foot-Optional (Extended Length Package of 2) (Not Included)
17	279318	Terminal, Tinned & Brass (3) (Includes Illus. 39)
18	3399585	Cabinet (Includes Illus. Nos. 5,7,15,41 And 57.)
19	98234	Clip, Ground
20	690363	Lock, Front Top (2)
21	695620	Panel, Front
23	685203	Clip, Felt Pad (3)
24	3389441	Catch, Door Assembly
26	337189	Clip, Hinge (2)
27	694091	Screw, 8-18 x 3/8
28	8066056	Hinge, R.H.
	8066057	Hinge, L.H.
33	696144	Strike, Door
35	695737	Door, Rear
36	3393549	Door, Front
37	690270	Handle, Door
38	3406129	Seal & Bearing Assembly
39	279393	Terminal Block Kit (For Terminal Block)
40	697776	Screw, 10-32 x 5/8
41	3397659	Block, Terminal
51	238088	Hinge, Top (2)
53	691366	Idler & Pulley Assembly
56	660996	Belt, Drive
57	348780	Base, Motor
58	3400500	Bolt, 5/16-18 x 3/4
59	3394341	Pulley, 60 Hz.
62	3976707	Motor Assembly 60 Hz.
63	660658	Clamp, Motor
64	3404162	Clamp, Motor (W/Shield)
67	3390731	Seal, Door
87	3393008	Screw, 10-16 x 1/2

TOP AND CONSOLE PARTS

For Model: LEQ8000HQ0

(Designer White)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

TOP AND CONSOLE PARTS

For Model: LEQ8000HQ0
(Designer White)

Illus. No.	Part No.	DESCRIPTION
1	3397545	Panel, Rear Console
2	3401684	Wire, Jumper (Black)
3	693995	Screw, Hex Head
4	3358528	Cap, End (L.H.)
5	8283127	Resistor Assembly
6	388326	Screw, Console
7	694419	Buzzer, Mini
8	3358513	Cap, End (R.H.)
9	3399642	Switch, Temperature
10	349639	Screen, Lint
11	688150	Cover, Lint Screen
12	339229	Hinge, R.H.
	339230	Hinge, L.H.
13	688983	Screw, 8-18 x 5/8
14	3400859	Screw, Grounding
15	3395683	Connector (Motor)
16	3396022	Top
17	3950759	Knob, Control
18	3394427	Clip-Harness
20	3401144	Connector, (PTS Relay)
21	3976573	Timer, 60 Hz.
22	3405156	Switch, Finish Guard
23	3397695	Wire, Jumper (Guard On/Off)
29	3390646	Screw, Mounting (8-18 x 5/16)
30	357213	Nut, Push-In (2)
31	8283128	Harness, Wiring
32	3977409	Wire, Jumper (Temperature)
33	3397269	Connector (Timer)
34	3347243	Connector 6-Circuit
35	94614	Terminal
39	3398095	Relay, Push-To-Start
48	3406143	Timer Knob Assembly
50	3936144	Connector
51	3977407	Control, Electronic
52	3391885	Connector, Edge
53	8054298	Bracket, Control
54	3976772	Panel, Control
55	343641	Screw, 10-16 x 1/2

OPTIONAL PARTS (NOT INCLUDED)

Illus. No.	Part No.	DESCRIPTION

PAINT, TOUCH-UP (1/2oz.)

72017	White
72107	Almond

PAINT, PRESSURIZED SPRAY (13 oz.)

350930	White
350956	Almond
350938	Primer, Gray

PAINT, BULK (1 qt.)

799344	White (Uncut)
978883	Almond (Uncut)

Following May Be Purchased

DO-IT-YOURSELF REPAIR MANUALS

LIT677818	Dryer

BULKHEAD PARTS

For Model: LEQ8000HQ0

(Designer White)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

BULKHEAD PARTS

For Model: LEQ8000HQ0

(Designer White)

Illus. No.	Part No.	DESCRIPTION
1	348368	Lint Chute Assembly
2	487909	Screw, 8-18 x 1/2
3	3388703	Washer-Support
4	347139	Seal, Lint Chute
5	90767	Screw, 8-18 x 3/8
6	696302	Shield, Exhaust
7	3392519	Thermal Fuse
8	3977425	Thermostat, Internal-Bias
9	3399848	Thermal, Cut-Off (Hi-Limit Thermostat Illus. No.15 Included)
10	694089	Wheel, Blower (Includes Illus. No. 22)
11	3405016	Housing, Blower
12	3398161	Clip
13	343641	Screw, 10-16 x 1/2
14	3397566	Box, Heater
15	3399693	Thermostat, 250°F (121.1°C)
16	3404232	Bracket, Drum Light
17	3403585	Element, Heater
18	3977358	Drum Hole Plug
19	279457	Wire Kit, Terminal (For Heater Element Wiring Harness Repair)
20	489463	Screw, 8-18 x 5/8
22	3394196	Seal, Blower
28	3394231	Clip, Sensor
29	298877	Washer, Insulated
30	348861	Pad, Sensor
31	348859	Electrode, Inside
32	348860	Electrode, Outside
33	3406124	Bulb
34	3402841	Lens, Drum Light
41	690997	Ring, Tri
42	3399506	Shaft, L.H.
43	3399507	Shaft, R.H.
44	3397588	Roller, Support
46	348197	Washer, Support
47	3359452	Nut, 3/8-16
48	3403414	Bulkhead
49	3403634	Socket Assembly
62	692526	Ring, Bearing (2)
63	97787	Screw, 11-16 x 3/4
66	3406130	Seal, Rear Drum
67	695587	Drum Assembly
68	692490	Baffle, Drum (2)
69	3976434	Bracket, Support
70	90296	Clip
71	3403636	Baffle, Drum (1)
73	339956	Seal